ELECTRIMOTION INC. 1484 DALE FORD RD. DELAWARE, OH 43015 740.362.0251

8971 POWER HARNESS

CONNECTOR:

2 PIN = POWER IN

8 PIN =

- 1 = +12 VOLTS 2 = 12 VOLT SUPPLY 3 = 12 VOLT SUPPLY 4 = RESET 5 = START 6 = 7 =
- 8 = GROUND

GROUND LEAD - GROUNDS TO CHASSIS AND POINT BOXES.

SWITCH:

GREEN WIRE IS START = ACTIVATE WHEN THROTTLE DOWN 60 PSI ACTIVATED

CARE SHOULD BE TAKEN TO ENSURE THAT THE SWITCH DOES NOT RESET WITH OUT PLENTY OF THROTTLE MOVEMENT!

RESET JUMPER:

UNPLUG JUMPER TO ACTIVATE SYSTEM FOR RUN AFTER THE BURN OUT! MOUNT ON HEAD PLATE OR ON MANAGEMENT BOX.

Visit us on the web at: www.electrimotion.com