

ELECTRIMOTION Inc.  
1484 Dale Ford Rd  
Delaware oh 43015  
740-362-0251

## System Air Shutoff



### Operation:

This device is designed to shut off ignition power in the event of an on board air system failure.

### Installation:

A 120 psi normally open air switch must be wired in series with the ignition “run enable” wire. In the event the system loses pressure below 120 psi, it will stop ignition from working. The switch must not remove power from the safety system or any other part of the car.

### Switch:

Honeywell PN [76055-00001000-01](#)

### Availability:

In stock \$120.00 as in picture with mounting hardware and 5/32 air fitting.